
HOLTKÖTTER INTERNATIONAL, INC.

155 Hardman Avenue South, South St. Paul, MN 55075

fax: (888) 552-8661 • phone: (800) 899-5444

www.holtkoetter.com
e-mail: customerservice@holtkoetter.com

Please make sure that the following parts for your fixture are enclosed.

- A column assembly consisting of:
- a threaded nipple
 - brass column piece
 - brass loop
 - brass bobèche

- A canopy kit consisting of:
- 4 feet of chain
 - hanging hardware
 - canopy

I. COLUMN ASSEMBLY

The fixture is pre-wired. The only things that need to be attached are the ball and the column.

1. Push the threaded nipple over the ground wire and the fixture wire.
2. Screw the threaded nipple into the coupling at the top of the fixture.
3. Slip the brass column and bobèche over the ground and fixture wire.
4. Thread the brass loop onto the threaded nipple.

The column assembly is now complete.

II. BOTTOM BALL ASSEMBLY

- The bottom ball kit includes:
- a threaded nipple
 - the brass ball
 - a brass finial

1. Thread the nipple into the coupling at the bottom of the fixture.
2. Slip the brass ball over the threaded nipple.
3. Thread the finial on until the brass ball is hand-tight against the fixture.

ASSEMBLY INSTRUCTIONS FOR

Holtkötter 2400 Chandelier Collection

2412/8+4



III. HANGING ASSEMBLY

1. Attach the chain to the top loop of the fixture and pull the wire through the chain.
2. Once the wire is pulled through the chain, attach the other side of the chain to the screw collar loop and screw the fixture bar over the 1/4 IP threaded nipple.

Now the fixture is ready to be hung.

IV. WIRING INTO THE OUTLET BOX

Connect the copper ground wire to the ground wire on the outlet box. The fixture wire (=lamp cord) has a marked side which is rough, and an unmarked side which is smooth. Holding your thumb over both sides of the wire, you can feel the rough and smooth part of the wire.

The rough side of the wire connects to the white (neutral) wire in the outlet box. The smooth side connects to the black (hot) wire in the outlet box.

Major fixture parts manufactured in Germany by Holtkötter Leuchten GmbH. Final assembly by Holtkötter International, Inc. in South St. Paul, MN.

Holtkötter® & Holtkötter Leuchten® are registered trademarks of Holtkötter International, Inc. All Rights Reserved.

© Holtkötter International, Inc.