
HOLTKÖTTER INTERNATIONAL, INC.

155 Hardman Avenue South, South St. Paul, MN 55075

fax: (888) 552-8661 • phone: (800) 899-5444

www.holtkoetter.com
e-mail: customerservice@holtkoetter.com

Please make sure that the following parts for your fixture are enclosed.

A column assembly consisting of:

- a threaded nipple
- brass column pieces
- brass loop
- brass bobèche

A canopy kit consisting of:

- 3 feet of chain
- hanging hardware
- canopy

I. COLUMN ASSEMBLY

The fixture is pre-wired. The only thing that needs to be attached is the column.

1. The column assembly is complete.
2. Thread the ground wire and fixture wire through the rod that holds the column pieces.
3. Screw the threaded nipple into the coupling at the top of the fixture.

II. HANGING ASSEMBLY

1. Attach the chain to the top loop of the fixture and pull the wire through the chain.
2. Once the wire is pulled through the chain, attach the other side of the chain to the screw collar loop and screw the fixture bar over the 1/4 IP threaded nipple.

Now the fixture is ready to be hung.

ASSEMBLY INSTRUCTIONS FOR

Holtkötter 2700 Collection (Flat Arm)
2796/6, 2738/8 & 2739/10



2738/8

III. WIRING INTO THE OUTLET BOX

Connect the copper ground wire to the ground wire on the outlet box. The fixture wire (=lamp cord) has a marked side which is rough, and an unmarked side which is smooth. Holding your thumb over both sides of the wire, you can feel the rough and smooth part of the wire.

The rough side of the wire connects to the white (neutral) wire in the outlet box. The smooth side connects to the black (hot) wire in the outlet box.

Major fixture parts manufactured in Germany by Holtkötter Leuchten GmbH. Final assembly by Holtkötter International, Inc. in South St. Paul, MN.

Holtkötter® & Holtkötter Leuchten® are registered trademarks of Holtkötter International, Inc. All Rights Reserved.

© Holtkötter International, Inc.