
HOLTKÖTTER INTERNATIONAL, INC.

155 Hardman Avenue South, South St. Paul, MN 55075

fax: (888) 552-8661 • phone: (800) 899-5444

www.holtkoetter.com

e-mail: customerservice@holtkoetter.com

Your floor lamp will come in two boxes, one for the shade and one for the base.

Assemble the floor lamp.

- I. Install the shade:
 - A. Unscrew the metal ring located on the socket of the lamp.
 - B. Place the shade over the center stem.
 - C. Screw the metal ring back into place, tighten hand-tight.
- II. Install the bulb of your choice (not included).
Maximum Wattage: 100 Watts, Medium Edison Base.
- III. Plug the foot dimmer into the cord.

Your lamp is now operational.

ASSEMBLY INSTRUCTIONS FOR

Adjustable Swing-Arm Floor Lamp 6348/1



Major lamp parts manufactured in Germany by Holtkötter Leuchten GmbH. Bulbs not included. Final assembly by Holtkötter International, Inc. in South St. Paul, MN.

Holtkötter® & Holtkötter Leuchten® are registered trademarks of Holtkötter International, Inc. All Rights Reserved.

© Holtkötter International, Inc.