

# HOLTKÖTTER®

The Ultimate Lighting Machines™

205 Hardman Avenue South, South Saint Paul, MN 55075  
Voice: (800) 899-5444 • Fax: (888) 552-8661  
e-mail: [customerservice@holtkoetter.com](mailto:customerservice@holtkoetter.com)  
[www.holtkoetter.com](http://www.holtkoetter.com)

## CAUTION, IMPORTANT SAFETY INSTRUCTIONS

This portable luminaire has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electrical shock. This plug will fit a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

## INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION OR INJURY TO PERSONS

## WARNING - To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION OR INJURY TO PERSONS:

1. Turn off power/unplug and allow to cool before replacing bulb.
2. Bulb gets HOT quickly. Contact only switch/plug when turning on.
3. Do not touch hot lens, guard or enclosure.
4. Do not remain in light if skin feels warm.
5. Do not look directly at lighted lamp.
6. Keep lamp away from materials that burn.
7. Use only with a 100 Watt, bayonet base halogen bulb or smaller bulb.
8. Do not touch the bulb at any time. Use a soft cloth. Oil from skin may damage bulb.
9. Do not operate the portable luminaire with a missing or damaged guard, lamp containment barrier or UV filter.

## SAVE THESE INSTRUCTIONS

## ASSEMBLY INSTRUCTIONS FOR Halogen Swing-Arm Floor Lamp No. 9424/1 & No. 9434/1

Please make sure that the following parts for your lamp are enclosed:

1. Lamp Base
2. Reflector Kit
  - A. Metal reflector (9424/1) **or** Glass reflector (9434/1)
  - B. Frosted glass shield
  - C. Bayonet base halogen bulb made by Osram in Germany (100 Watts)
  - D. Dimmer knob and stem
  - E. Allen wrench



9424/1



9434/1

# HOLTKÖTTER®

e-mail: customerservice@holtkoetter.com

www.holtkoetter.com

## Installation Instructions

1. Insert the bulb into the bayonet socket. The bulb is inserted by pushing it slightly down into the socket and then turning it clockwise. **NOTE: BE CAREFUL NOT TO TOUCH THE BULB WITH YOUR BARE HANDS.**
2. Set the glass shield (B) on the grooved counterpart of the reflector (A).
3. Screw the reflector onto the base. Holding the reflector with one hand, and the glass shield with the other hand, place the reflector and glass shield over the bulb and onto the base. Turn the reflector clockwise until it is completely assembled.
4. Lower the dimmer stem through the hole in the bracket on the main stem into the small dimmer knob on the base, being careful not to scratch the stem surface. Tighten the setscrew on the small dimmer knob (near the base) with the allen wrench provided. (See diagram.)
5. Plug lamp into your outlet. Turn the knob (D) located next to the stem for on/off and dimming controls. The lamp is now operational.

## Care Instructions

Use only a soft, dry cloth to clean. If necessary, a slightly damp, soft cloth can be used to spot clean. Do not use common household cleaners on lamps or fixtures, as the lacquer on the outside of the brass may be damaged as a result.

Enjoy your new Holtkötter lamp.

# ASSEMBLY INSTRUCTIONS FOR Halogen Swing-Arm Floor Lamp No. 9424/1 & No. 9434/1

## Assembly Diagram

